MODEL: 60525WH

PACKING DIAGRAM









ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

UNPACK THE LAMP

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: HANDLE, SOLAR DISC AND LANTERN BODY. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

ASSEMBLE THE LAMP

1. TURN ON THE LED LIGHT BY PRESSING THE SWITCH BUTTON.

NOTE: LED LIGHT ONLY WORK AT NIGHT.

2. PLACE SOLAR DISC ON TOP OF THE LANTERN BODY.

3. ATTACH THE HANDLE INTO THE HOLES IN LANTERN BODY.

TROUBLE SHOOTING:

1. IF YOUR LED LIGHT DOES NOT WORK, CHECK THE SOLAR DISC IS RECEIVING SUNLIGHT DIRECTLY AND NOT IN SHADOW.

2. ALTHOUGH THERE MAY BE SOME INITIAL CHARGE IN BATTERY, WE RECOMMEND FULLY CHARGING IT BEFORE FIRST USE. TURN OFF THE LED LIGHT AND LEAVE THE SOLAR DISC IN GOOD SUNLIGHT FOR 4~5 HOURS TO ENSURE THE BATTERY IS FULLY CHARGED.

3. THE FULL RUN TIME OF THE LED LIGHT IS 6~8 HOURS WHEN THE BATTERY IS FULLY CHARGED.

4. TO GET BEST PERFORMANCE FROM THE SOLAR DISC IN THE SUNSHINE, PLEASE MAKE SURE THAT YOU PERIODICALLY CLEAN THE TOP SURFACE OF THE SOLAR DISC (DO NOT USE A CHEMICAL SOLVENT).

5. IF THE LED LIGHT STILL DOES NOT WORK, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

BATTERY INFORMATIONS:

* RECHARGABLE BATTARY BECOME LESS EFFICIENT WITH REPEATED CHARGE AND DISCHARGE CYCLES, THE CAPACITY OF THE BATTERY MAY REDUCE OVER TIME. IF YOU FIND THAT THE BATTERY APPEAR LESS EFFICIENT, TRY TO BOOST CHARGE IT. TO DO THIS, LEAVE OFF THIS SOLAR DISC FOR 2~3 DAYS IN SUNNY DAYS TO ALLOW THE MAXIMUM CHARGE TO THE BATTERY. WE RECOMMEND THAT YOU DO THIS OCCASIONALLY TO HELP PROLONG THE LIFE OF BATTERY. IF YOUR BATTERY STILL DOES NOT WORK WELL AFTER THIS BOOST CHARGE, YOU SHOULD REPLACE THE BATTERY.

** AFTER THE BATTERY USED FOR 12~18 MONTHS, IT MAY HAVE REACHED IT'S SERVICE LIFE, YOU SHOULD REPLACE THE BATTERY.

AVAILABLE PART IS:
SOLARDISC (SOLAR DISC)